



### **Solar Glide Fitting Instructions**

#### **Tools Required**

Bradle  
Measuring Tape  
Scissors  
Sharp Knife  
Small piece of scrap wood

#### **Components**

Blue SmartClic x 10  
Short Sleeve Straps x 5  
Pulling strap assembly x 1  
Plastic Buckles x 5  
Foam Rods x 4  
Net Sleeve x 1

- Ensure that the solar cover fits the pool. Solar covers are made slightly oversized on the length to allow for possible shrinkage. Bear this in mind before trimming on site.
- Lay one end of the solar cover on the pool surround bubble side down.
- Lay out the Net Sleeve and feed one tail of the Net Sleeve under the edge of the solar cover and the other tail of the Net Sleeve on top of the solar cover. Ensure that the edge of the solar cover is fully inserted between the two tails of the Net Sleeve.
- Slide the Net Sleeve along the edge of the solar cover so that one end of the Sleeve is level with one side of the solar cover.
- Cut the other end of the Net Sleeve so that it is level with the other side of the solar cover.
- At one end of the Net sleeve slide the piece of scrap wood under the whole assembly.
- Using the Bradle make a hole through the assembly 1" (25mm) from the back edge of the Net Tail and 8" (200mm) from the outside edge of the Net tail.
- Take one Short Sleeve Strap and thread it through the slot in the buckle nearest the square end of the buckle.
- Place one end of the Short Sleeve Strap above the hole you have made and the other end below the hole you have made.

- Take the male two pronged part of the Blue Fixing Toggle and push it down through the cover, making sure that you line the toggle hole with the one that you have made in the assembly.
- Take the female part of the Blue Fixing toggle and press it over the two prongs of the male toggle on the bottom side of the assembly.
- Take the remaining section of the toggle and screw down into the already assembled two sections until tight. Take care not to over tighten.
- Repeat this operation at the other end of the Solar Glide.
- Then repeat this operation in the centre.
- Then halving the distance between the centre and outer straps, repeat operation with remaining two straps and smartclips.
- Push the foam Rods into the sleeve pocket and trim off any surplus foam rod using a sharp knife. The foam rods should be flush with the end of the net sleeve pocket.
- Take the Pulling strap assembly and lay it out on the pool surround in front of the net sleeve. Attach the three pulling straps to the buckles (centre strap is the shortest). Thread the end of each strap up through the centre slot in the buckle and then down through the slot nearest the curved end of the buckle.
- Adjust all five buckles so that the three pulling straps have equal tension.
- Place solar cover and Solar Glide onto pool for use.