Certikin

Witan Park, Avenue 2, Station Lane Industrial Estate Witney, Oxon OX8 6FH

UK Tel: 01993 778855 UK Fax: 01993 778620 Overseas Tel: 44 1993 700744 Overseas Fax: 44 1993 708499

PART Nos HD 100SN & HD 101S SURFACE WATER SKIMMER W/A EXTENSION THROAT FOR CONCRETE POOL INSTALLATION





Witan Park, Avenue 2, Station Lane Industrial Estate Witney, Oxon OX8 6FH

UK Tel: 01993 778855 UK Fax: 01993 778620 Overseas Tel: 44 1993 700744 Overseas Fax: 44 1993 708499 PART Nos HD 100SN & HD 101SL SURFACE WATER SKIMMER W/A EXTENSION THROAT FOR CONCRETE BLOCK-WALLED LINER POOL INSTALLATION





Apply gasket to front face of extension throat.

IMPORTANT Do not fit liner clamp flange until water level has reached the level of the throat.

After liner is in place, feel through liner for holes in gasket/throat face and offer clamp flange to throat ensuring all 16 holes are aligned. Using self-tapping screws provided, secure clamp flange to throat through pool liner and gasket.

Carefully cut liner material from centre of throat aperture. Finish using clip-on cover plate.



ALL PIPEWORK AND POOL FITTINGS MUST BE PRESSURE TESTED BEFORE BACKFILLING

CERT04



Witan Park, Avenue 2, Station Lane Industrial Estate Witney, Oxon OX8 6FH

UK Tel: 01993 778855 UK Fax: 01993 778620 Overseas Tel: 44 1993 700744 Overseas Fax: 44 1993 708499

- (1) Height adjustable lid covered in protective film (to be removed when pool complete)
- 2 Strainer basket
- 3 Weir plate
- 4 1" metric/imperial water fill-up connection port with knockout
- (5) 1" metric/imperial overflow connection port with knockout
- (6) 1.5" imperial pump suction connection
- 7 1.5" metric equivalent pump suction connection
- 8 Front finishing plate
- (9) 2 part liner plate adaptor
- (10) Clamp plate

NOTES:

- 1) Ensure that skimmer is set square and level.
- 2) Debris and concrete should be prevented from entering skimmer unit during construction.
- Liner pool adaptor plate should be used as a template for 7No holds after aperture has been cut out.
- Liner should be trimmed out as tightly to inside edge of skimmer throat as possible.
- 5) Any threaded connections should be made with PTFE tape, NOT liquid jointing.

293









INSTALLATION OF CERTIKIN HD100LAK SKIMMER LINER ADAPTOR KIT





ALL PIPEWORKAND POOLFITTINGS MUST BE PRESSURE TESTED BEFORE BACKFILLING

CERT04