

ULTRA VAC CART









Operation Instructions

- 1. Remove pump lid by turning anti clockwise.
- 2. Once removed fill the pump housing with water. Ensure that the basket is located correctly and in position.
- 3. Replace the lid ensuring that the O ring is located correctly and lubricated with an approved O ring lubricant.
- 4. Connect the return vacuum hose to the hose adaptor located on top of the Multicyclone Plus. We recommend to use a clamp to ensure a tight seal.
- 5. Connect your telescopic handle to the vacuum head of your choice depending upon the surface being cleaned.
- 6. Connect the vacuum hose to the vacuum head.
- 7. Place the vacuum head on the bottom of the pool, water feature or water body that is being cleaned.
- 8. Place the hose into the water to ensure that the hose is full of water and all air is expelled.
- 9. Connect the vacuum hose to the hose adaptor located on the suction side of the pump. We recommend to use a clamp to ensure a tight seal.
- 10. Turn the pump on by turning the isolator switch to the "on" position.
- 11. Proceed to clean the pool, water feature or water body.
- 12. Periodically inspect if the strainer basket requires cleaning and if so, proceed to empty the basket.

Cleaning of filter cartridge

- 1. Remove the lid of the Multicyclone Plus by unscrewing the clamp arrangement at the top of the unit and removing.
- 2. Remove the cartridge element from the housing.
- 3. Clean the filter cartridge with clean water, by hosing or soaking in a dedicated cartridge cleaner as necessary.

 After time the cartridge may need to be replaced and if this is the case the replacement cartridge item code is 62451.
- 4. Once clean, place the cartridge element back into the housing ensuring that it is located correctly.
- 6. Replace the cover.
- 7. Re-fit the clamp hand tight. This will produce a water tight seal.