

Backwash Guide

- 1. Turn off pump.
- 2. Turn multiport valve handle to backwash.
- 3. If there is a valve on the waste open it.
- 4. Turn on pump.
- 5. Allow to run for at least 60 second or until sight glass runs clear.
- 6. Turn off pump.
- 7. Turn multiport valve handle to rinse.
- 8. Turn on pump for 15-20 seconds.
- 9. Turn off pump.
- 10. Turn multipart valve handle back to filtration.
- 11. Close valve on waste-line if fitted.
- 12. Turn on pump.

This procedure should be carried out at least weekly during the season. More often during heavy use.

If you require any further assistance please do not hesitate to contact us, we will be more than happy to help with any questions or queries.

TECHNICAL HELPLINE - 01747 839608